

Touchscreen Remote (V2001) Quick Operations Guide

The Touchscreen Remote (V2001) is compatible with select OASIS and HURRICANE heaters:

- OASIS ZEPHYR
- HURRICANE ZEPHYR
- HURRICANE SCH25

Please contact ITR for the installation procedure of the module. This manual describes the operating of the Touchscreen Remote.

ITR's advanced Touchscreen Remote is designed with the user in mind. An easy to use interface displays system controls, a help menu, fault detection, and system settings, all controlled with a simple touch of the screen.

Features:

- Intuitive Controls
- High Quality Interface
- On Screen Help Menu
- Error Detection
- Burner ON/OFF Control
- Heater Status Indicators
- Android/iOS App


US

5305 NE 121st Ave., Suite 401
Vancouver, WA 98682
Telephone: (360) 993-4877
Fax: (360) 993-1105
Toll Free: 1-800-993-4402
Email: info@itrheat.com

CANADA


2431 Simpson Road
Richmond, BC V6X 2R2
Telephone: (604) 278-1274
Fax: (604) 278-1274
Toll Free: 1-800-775-1272
Email: info@itrheat.com


Main screen:





The Touchscreen Remote displays the operating mode of the heater and gives some brief explanation of its status. Some of the main operating modes are:

- Burner On
- Heater Cycling
- Burner Off
- Thermostats Off


 **Screen Off button:** Turns the screen OFF. All the controls will remain active. To turn the screen ON, touch anywhere on the screen.

 **Menu button:** Displays the Settings and Help buttons on the top right corner of the screen. Touching the Menu button again will remove those buttons. If not selected, Settings and Help buttons will be removed from the screen after few seconds.

 **Help button:** Displays the help screen for the current operating mode. In case of a fault, the help screen shows solutions to clear the fault.

 **Settings button:** Displays the settings screen. The screen is described in the next page.

Burner buttons: Turn the diesel burner ON and OFF.

 **Wi-Fi icon:** Indicates if an active Wi-Fi connection is established. The icon will be pale when there is no active connection.

Settings screen:



Settings screen enables user to control different features of the Touchscreen remote:

Buzzer: The buzzer will sound the alarm for about 5 seconds in case of a fault. The alarm can be turned OFF and ON using this button.

Screen: The screen will turn OFF automatically if not touched for few minutes. It will turn ON again any time the screen is touched. The timeout can be set using this button to 1, 3 or 5 minutes.

Network: The connected network name and the Heater ID are displayed if an active network is connected. Otherwise, use this button to go to the network settings screen. The Heater ID is used on Android or iOS APP to connect to the heater.

When finished selecting the appropriate settings, touch the Exit button to save the selection and go back to the Main screen. The screen will switch back to Main screen if no action is done for one minute.

Network screen:




Available Wi-Fi networks will be shown a few seconds after entering this screen. You can select the desired Wi-Fi network to connect to by touching the name and then go to the next screen to enter the password.

If your router has the WPS feature, you can use it to connect to the Wi-Fi and skip the entering the password step.

To use WPS, first push the WPS button on your router, then touch the WPS button on this screen. The system will attempt to connect to the Wi-Fi network.

Password screen:



Use the row of letters in this screen to enter the password for your selected Wi-Fi. The arrows at the left and right of the row let you scroll through the set of letters that is selected. The password characters will show up in the second line on this screen as entered.


Aa1# There are four sets of characters that you can select to choose from: uppercase letters, lowercase letters, numbers and special characters. Scroll through these four sets by touching this button.

CLR Clear the whole entered password by touching this button.

BS This is the Back-Space button. Touch it to clear the last entered password character.

After entering the password, touch the Save button. The entered password is saved and the Touchscreen remote attempts to connect to the selected Wi-Fi. If unsuccessful, this screen with the entered password will be displayed again. You can correct or change the password and try again.

Using App:



You can enjoy monitoring and controlling your heater from your cellphone using ITR OASIS App.

Download the ITR OASIS App from Google Play Store or iPhone App Store and install it on your phone.

Go to the App's Settings screen. Enter a name for your heater and enter the Heater ID in the related spaces and save. The Heater ID can be found on the Settings screen of your Touchscreen remote if connected to the Wi-Fi.

The App's main screen will display the heater status and you can turn on and off the burner remotely.